

## **For GBD Remote Instruction**

**CODE LEARNING:** Press the button SW3, the LED LD1 comes on (it remains on for 6 seconds, then goes off).

Press the preselect key of the radio control, the LED goes off and the receiver delivers a pulse with the relay.

With the four channel receiver, channel activation is automatic. Therefore, at the time of self-learning, it suffices to press any key of the radio control and all the channels will be operational. Without pressing the SW3 key again, further remote controls of the same family can be learned, one after the other. After learning the last remote control, wait for the LED to go off (about 6 seconds) indicating that the system has exited TX learning and is ready to operate normally.

**MEMORY RESET:** If a mistake is made or if all the codes need to be deleted, press the SW3 key (the red LED comes on) and hold it pressed down until the LED goes off again.